

INSTRUCTIONS FOR USE

BEFORE USING THE REFRIGERATOR

SAFEGUARDING THE ENVIRONMENT

PRECAUTIONS AND GENERAL RECOMMENDATIONS

HOW TO OPERATE THE REFRIGERATOR COMPARTMENT

HOW TO OPERATE THE "EXTRA-COLD" COMPARTMENT

HOW TO OPERATE THE FREEZER COMPARTMENT

HABITUAL NOISES


CARE AND MAINTENANCE

TROUBLESHOOTING GUIDE

AFTER-SALES SERVICE

INSTALLATION

ELECTRICAL CONNECTION



FREEZER COMPARTMENT

1. Fast freezing compartment
2. Ice cube trays
3. Shelf
4. Freezer door trays (if fitted)
5. Freezer control panel

REFRIGERATOR COMPARTMENT

6. Extra-Cold Compartment
7. Refrigerator thermostat knob
8. Refrigerator inside light
9. Adjustable glass shelves
10. Crisper drawer
11. Air circulation system with anti-odour filter
12. Egg tray
13. Door trays
14. Bottle rack
15. Can holder (if provided)
16. Adjustable feet

BEFORE USING THE REFRIGERATOR

Your new appliance is a combined ventilated, no-frost fridge-freezer exclusively for domestic use.

The great advantage of this appliance is that the refrigerator and freezer compartments are ventilated, therefore there is no ice or frost formation on the walls, thanks to the process described below. The cold is produced by an evaporator and distributed to the single compartments by means of a fan.

The air, after circulating in the compartments, is absorbed again by the evaporator, which also retains any humidity in the air. This prevents frost from forming on the compartment walls, as in traditional appliances, therefore **there is no need to defrost the appliance.**

The humidity absorbed by the evaporator is transformed into water, which is automatically routed to a container located on the compressor, from where it evaporates. The ventilated refrigeration system guarantees optimal food storage, maintaining the original characteristics longer.

To get the most out of your new appliance, read the user handbook thoroughly. The handbook contains a description of the appliance and useful tips for storing food.

Keep this handbook for future consultation.

1. After unpacking the appliance, check for damage and make sure that the doors shut properly. Any damage must be reported to your dealer within 24 hours after delivery of the appliance.
2. **Wait at least two hours without moving the appliance before switching on. This will give the refrigerant circuit time to settle and operate efficiently.**
3. Installation of the appliance and electrical connections must be carried out by a qualified electrician, in accordance with the manufacturer's instructions and local regulations.

SAFEGUARDING THE ENVIRONMENT

1. Packing

The packaging material is entirely recyclable, and marked with the recycling symbol. Follow local regulations for scrapping.


Keep the packaging materials (plastic bags, polystyrene parts, etc.) out of reach of children, as they are potentially dangerous.

2. Appliance

The appliance is made using recyclable materials. Disposal must be carried out in accordance with local environmental regulations for waste disposal. Make the appliance unusable by cutting off the power cord. The appliance must be delivered to an authorised collection centre for the recovery of refrigerant gas.

Information:

This appliance does not contain CFCs (replaced with R134a) or HFCs (replaced with R600a-Isobutane). For more information, refer to the identification data plate affixed to the appliance.



PRECAUTIONS AND GENERAL RECOMMENDATIONS

- Use the **refrigerator compartment** only for storing fresh food and beverages and use the freezer compartment only for storing frozen food, freezing fresh food and making ice cubes.
- Do not cover or obstruct the air vents of the appliance.
- Do not store liquids in glass containers in the freezer compartment - danger of bursting.
- Do not eat ice cubes or ice lollies immediately after taking them out of the freezer compartment - risk of "cold" burns.
- Do not allow children to play or hide inside the appliance - risk of becoming trapped and suffocating.
- Do not ingest the contents (non-toxic) of the ice packs (if provided).
- **Before servicing or cleaning the appliance, unplug it from the mains or disconnect the electrical power supply.**
- The power cable may only be replaced by an authorised person.
- After installation, make sure that the refrigerator is not standing on the power supply cable.

Declaration of conformity

This appliance is intended to come into contact with foodstuffs and conforms to D.L. 108 of 25.01.1992 (European Directive 89/109/EEC).



Information

Appliances with Isobutane (R600a).

Isobutane is a natural gas with low environmental impact. Caution is required, however, since isobutane is flammable. Therefore, it is essential to ensure that refrigerant pipelines are not damaged.

HOW TO OPERATE THE REFRIGERATOR COMPARTMENT

The refrigerator compartment is designed for the storage of fresh food and beverages.

Defrosting of the refrigerator compartment is completely automatic.

The refrigerator can operate at ambient temperatures between +16°C and +43°C. Optimal performance is obtained at temperatures between +18°C and +43°C.

Switching on the appliance

- Plug in the appliance.
- The appliance will switch on automatically.
- The inside light switches on when the refrigerator door is opened.

Using the refrigerator

- Adjusting the temperature.

For correct operation and optimum storage of food, adjust the temperature in the refrigerator and freezer compartments separately.

Refrigerator thermostat

To adjust the temperature in the refrigerator compartment, turn the thermostat knob to the desired position.


TEMPERATURE	TYPE OF USE
Minimum	Small amounts of food stored. The door is seldom opened.
Medium	Normal use.
Maximum	Large amounts of food stored. The door is opened frequently.

- After being switched on, the refrigerator needs approximately 2 hours to reach the correct temperature to store a typical volume of food in the refrigerator compartment.

Moisture control

Some foods, such as fruit and vegetables, lose moisture when stored in cold, dry places. The crisper drawer maintains the right temperature and moisture level for storing fruit and vegetables. Using the Control Device, it is possible to adjust the airflow inside the crisper drawer.

- We recommend you keep the Control Device closed when storing vegetables and open when storing fruit.



How to use the refrigerator compartment


To maintain the vitamins, aroma, substance and freshness of the food to be stored, it is advisable to wrap food in aluminium foil, cling film or place it in special freezer containers with lids. This will prevent odours from mixing. Your refrigerator has an anti-odour system; the anti-odour filter is located in the cool air duct.

Important

Since appliance internal temperature is to all intents and purposes uniform thanks to the new ventilated system (**MULTI-FLOW**), foods can be arranged on any shelf. However, take care not to obstruct the air vents in order to allow air to circulate freely.

- Do not place hot food in the refrigerator.

MULTI-FLOW



HOW TO OPERATE THE “EXTRA-COLD” COMPARTMENT


The temperature inside this compartment is maintained constant and is colder than in other parts of the refrigerator. Dairy products can be stored in this compartment longer and drinks are chilled more rapidly; It can be used to store dairy products, cold meats and meat.


- If necessary, remove the extra-cold compartment, taking all the food out first. Pull the drawer out fully. Then, holding the compartment with both hands, carefully lift it up and out.
- It is not advisable to remove the tilting door from the extra-cold compartment.

HOW TO OPERATE THE FREEZER COMPARTMENT





The freezer compartment can be used for freezing fresh and cooked food, making ice cubes and storing frozen food.

Freezer control panel

- To adjust the temperature in the Freezer compartment, select the desired freezing level using the  button on the control panel.



1. Operation LED
2. Door open alarm
3. Alarm mute button
4. Fast Freezing

	Minimum level: to be used when small amounts of food are stored in the Freezer and the door is seldom opened.
	Medium level: to be used in normal conditions.
	Maximum level: to be used when large amounts of food are stored in the Freezer and the door is opened frequently.
	Fast Freezing: the three LEDs are alight. Select the Fast Freeze function for colder temperatures. This function switches off automatically after 18 hours.

ELECTRONIC CONTROL

This appliance is provided with an exclusive electronic control system. Thanks to this system, appliance operation is constantly monitored.

- In the event of a malfunction, the control system will activate an acoustic alarm and the LEDs on the control panel will blink.
- This system controls door closure. If a door is open, close it. The acoustic alarm is deactivated.
- This system also controls the internal temperature of the appliance. The acoustic alarm will sound if the internal temperature increases. Do not place hot food in the appliance.
- To mute the acoustic alarm press the "Alarm" button. The LEDs blink until the ideal internal temperature is reached.
- This electronic control system also has an auto check function. An acoustic alarm will immediately signal any malfunction in your appliance. This allows you to contact the After-sales Service to solve the problem rapidly.
- When the LEDs blink, the appliance should not be used for a prolonged period of time. Contact the After-sales Service as soon as possible.
- After approx. two hours, the acoustic alarm also signals the malfunction. Press the "Alarm" button. Unplug the appliance from the mains socket until the problem is solved by the After-sales Service.

Important:

- After switching on, the freezer compartment takes approximately 3 hours to reach a suitable temperature for frozen food storage.

How to freeze fresh food

You can use the freezer compartment to freeze food.

The amount of fresh food that can be frozen in 24 hours, at an ambient temperature of + 25°C, is indicated on the data plate.

How to proceed:

1. 24 hours before freezing fresh food, press the fast freeze button.
2. Wrap and seal the food in aluminium foil, cling film, air and water-tight plastic bags, polythene containers with lids, freezer containers.
3. Place food in the upper part of the freezer, leaving enough space for air to circulate around packs.
4. For more efficient freezing, use the fast freeze function for the next 24 hours.
5. When freezing is complete, press the fast freeze button again.

Note:

- In the event of a power failure, the freezer compartment maintains the correct storage temperature for about 9/10 hours.
- Do not open the freezer compartment door during a power failure.

Important:

The table alongside shows the recommended maximum storage time for frozen fresh foods.

When purchasing frozen food products:

- Ensure that the packaging is not damaged (frozen food in damaged packaging may have deteriorated). If the package is swollen or has damp patches, it may not have been stored under optimal conditions and defrosting may have already begun.
- When shopping, leave frozen food purchases until last and transport the products in a thermally insulated cool bag.
- Place the items in the freezer compartment as soon as you get home.

Important:

- Do not place hot food in the freezer.
- Wrap foods in aluminium foil or cling film or place them in specific containers.
- Ensure all packs placed in the freezer have a label indicating the date of freezing and content.
- If food has defrosted even partially, do not re-freeze it. Consume within 24 hours.
- Avoid, or reduce temperature variations to the minimum.
- Respect the best-before date on the package.
- Always observe the storage information on the package.

Making ice cubes

Bend the ice trays slightly to remove ice cubes.

If your appliance is provided with the "Twist-Ice" feature, proceed as follows:

- Lift the ice cube tray and take it out.
- Fill the ice cube tray with water, being careful not to exceed the maximum level (indicated by the arrow).
- To remove the ice cubes just turn the lever with one twist clockwise.


The ice cubes conveniently fall into the ice bucket.

Important:

Do not leave water in the ice bucket.


MONTHS**FOOD**

1-3			
4-7			
8-12			



HABITUAL NOISES

Some noises are normal when the appliance is operating.



Breaking ice:	Ice may break when moved. The noise is the same as that made by ice cubes when exposed to ambient temperature.
Compressor noise:	Normal motor noise. This noise means the compressor is operating normally.
Gas expansion noise:	It is normal to hear the noise of the expansion gas in the refrigeration system. This noise is similar to a balloon being inflated.
Defrost noise:	Normal noise of flowing water. This can be heard when the unit is defrosting.
Fan system noise:	Normal fan noise. This noise can be heard when the Multi-Flow system is operating normally. This system ensures a uniform temperature in the refrigerator so that defrosting is no longer necessary.

CARE AND MAINTENANCE

Before carrying out any cleaning operations, unplug the appliance.

- Clean the inside of the freezer compartment when defrosting.
- Periodically clean the inside of the refrigerator compartment with a sponge dampened in warm water and/or neutral detergent. Rinse the interior and dry with a soft cloth. Do not use abrasive products.
- Clean the outside with a damp cloth. Do not use abrasive products, scourers, stain-removers (e.g. acetone, trichloroethylene) or vinegar.
- Both refrigerator and freezer compartments are provided with an automatic defrosting function (no frost system).
- **Periodically clean the condenser (radiator) at the rear of the appliance and the plinth with a vacuum cleaner or brush.**

Prolonged disuse

1. Empty the refrigerator and freezer compartments
2. Disconnect the appliance from the mains power supply
3. Clean and dry both refrigerator and freezer compartments
4. Leave the doors open to prevent formation of unpleasant odours.



TROUBLESHOOTING GUIDE

1. **The appliance is not working.**
 - Is there a power failure?
 - Is the plug properly inserted in the socket?
 - Is the double-pole switch on?
 - Has the fuse blown?
 - Is the power cord in perfect condition?
2. **Temperature inside the compartments is not low enough.**
 - Are the doors closed properly?
 - Is the appliance installed near a heat source?
 - Is the thermostat setting correct?
 - Are the air circulation grilles blocked?
 - Is the condenser clean?
3. **Temperature inside the refrigerator compartment is too low.**
 - Is the thermostat setting correct?
4. **The appliance is excessively noisy.**
 - Is the appliance in contact with other furniture or objects?
 - Are the pipes at the back touching or vibrating?
5. **The inside light is not working.**

Perform the checks for problem 1, and then:

 - Remove the shelf to allow access.
 - Use a screwdriver to prise off the transparent bulb cover.
 - Unscrew the bulb and replace it with one of the same type (max. 15 Watt), available from our After-sales Service.
 - Refit the cover by pushing it gently into place.
6. **The acoustic alarm is activated and the "Door open" LED blinks.**
 - The door has been left open for too long: Close the door. Press the "Alarm mute" button if you need to leave the door open for a prolonged period of time.
7. **The acoustic alarm is activated and all the LEDs blink.**
 - The door has been left open for too long: Close the door.
 - Refrigerator component malfunction: Press the "Alarm mute" button to deactivate the acoustic alarm. Contact the After-sales Service.

AFTER-SALES SERVICE

Before contacting After-Sales Service:

1. See if you can solve the problem yourself with the help of the Troubleshooting guide.
2. Switch the appliance on again to see if the problem has been solved. If it has not, disconnect the appliance from the power supply and wait for about an hour before switching on again.
3. If the problem persists after this course of action, contact After-sales Service.

Specify:

- the nature of the problem,
- the model,
- the Service number (the number after the word SERVICE on the data plate on the inside of the appliance),
- your full address,
- your telephone number and area code.

SERVICE 0000 000 00000



Note:

The direction of door opening can be changed. If this operation is performed by After-sales Service it is not covered by the warranty.

INSTALLATION


- Install the appliance away from heat sources.
- Install the appliance in a dry, well-ventilated place.
- Ensure that the appliance is level. Adjust the front feet if necessary.
- Leave at least 5 cm clearance above the appliance.
- The sides of some models are extended at the rear so the appliance can be placed directly against the rear wall. Otherwise, fit the spacers (if supplied) on the upper part of the condenser at the rear of the appliance. For models without spacer walls, the distance between the unit and the wall must be at least 4.5 cm.
- Clean the inside (see the chapter "Care and Maintenance").
- Fit the accessories supplied.

Electrical connection

- Electrical connections must be made in accordance with local regulations.
- Ensure that the voltage indicated on the appliance data plate corresponds to the domestic supply voltage.
- **Regulations require that the appliance is earthed. The Manufacturer declines all liabilities for injury to persons or damage to property resulting from failure to observe these regulations.**
- If the plug and socket are not of the same type, have the socket replaced by a qualified electrician.
- Do not use extension cables, multiple sockets or adapters.

Disconnecting the appliance

It must be possible to disconnect the appliance by unplugging it or by means of a two-pole switch fitted upline of the socket.



ELECTRICAL CONNECTION

For Great Britain only

Warning - this appliance must be earthed

Fuse replacement


If the mains lead of this appliance is fitted with a BS 1363A 13amp fused plug, to change a fuse in this type of plug use an A.S.T.A. approved fuse to BS 1362 type and proceed as follows:

1. Remove the fuse cover (A) and fuse (B).
2. Fit replacement 13A fuse into fuse cover.
3. Refit both into plug.

Important:

The fuse cover must be refitted when changing a fuse and if the fuse cover is lost the plug must not be used until a correct replacement is fitted.

Correct replacement are identified by the colour insert or the colour embossed in words on the base of the plug. Replacement fuse covers are available from your local electrical store.



Socket outlet / plug

If the fitted plug is not suitable for your socket outlet, please contact Whirlpool Service on 0870 600 8989 for further instruction. Please do not attempt to change plug yourself. This procedure needs to be carried out by a qualified Whirlpool technician in compliance with the manufactures instructions and current standard safety regulations.

For the Republic of Ireland only

The information given in respect of Great Britain will frequently apply, but a third type of plug and socket is also used, the

2-pin, side earth type. In this case, the wire which is coloured GREEN AND YELLOW must be connected to the EARTH contact, and the two wires to the two pins, irrespective of colour. The supply to the socket must be fitted with a 16 amp fuse.